

1

2

3

4

5

6

Dosing / Return Valve (DRV)
G 1/2" iso 228-1 female
Manual air relief valve

Dosing line with
check valve

Pressure Relief Valve (PRV)
G 3/8" iso 228-1 female
Set pressure 20bar
(Only on DRV version)

Supervisory
Switch
1NC+1NO

Flushing line with filter

Manual air
relief valve

Version without
Dosing / Return Valve
(DRV)

WARNING!
Do not use the piping
to lift the unit!

A

B

A

B

WATER INLET

WATER CONNECTION
G 2 1/2" iso228-1 male

CONCENTRATE INLET
G 1" iso 228-1
female

Selector valve
Dosing/Flushing

WATER/CONCENTRATE
OUTLET

Optional:
ANSI/AWWA C606-04
Cut groove DN65 (73)

4x M10x20
Water motor mounting holes
See user manual

4x Ø13
Pump bracket mounting holes
See user manual

C

C

D

D

FM Approved when used together with FM Approved
foam concentrates and discharge devices

Dimensions tolerance ± 1mm unless otherwise noted
NOTE! Reverse water flow direction is optional
We reserve the right to make changes without prior notice

Drawn by WALLE	Checked by	Approved by - date MKA	File name	Date 2017-12-28	Scale 1:12
-------------------	------------	---------------------------	-----------	--------------------	---------------

Firemiks AB			DD - 2302		
P.O.Box 8155			FIREMIKS 800-3-PP-F-FM		
SE-104 20 STOCKHOLM, Sweden			Copyright of Firemiks AB		
info@firemiks.com +46-8-551 196 10			All rights reserved		Edition
					Sheet 1/1

1

2

3

6